
Contents

Figures	v
Acknowledgments	xi
Introduction	1
1 Where Do Oil and Gas Come From?	3
Characteristics of Rocks	3
Origin of Oil and Gas	5
Traps	8
Reservoir Fluids	11
Summary	12
2 Exploring and Drilling for Oil and Gas	13
Exploration	13
Leasing	18
Drilling	18
Summary	26
3 Drilling Wells Offshore	27
Platforms	27
Deepwater Drilling	31
Summary	31
4 Testing and Completing Wells	33
Formation Testing	33
Perforated Completions	34
Open-Hole Completions	36
Perforated Liner Completions	36
Wire-Wrapped Screen Completions	37
Tubing and Packers	38
Tubingless Completions	40
Multiple Completions	40
Summary	41
5 Stimulating Reservoirs	43
Fracturing	44
Acidizing	44
Summary	46
6 Driving Reservoir Production	47
Dissolved-Gas Drives	47
Gas-Cap Drive	48
Water Drive	49
Combination Drive	50
Summary	51
7 What Controls the Well?	53
Casinghead	53
Tubing Head	55
Christmas Tree	56
Summary	58

8	Lifting More Oil and Gas	59
	Beam Pumping	59
	Subsurface Hydraulic Pumping	65
	Electric Submersible Pumping	67
	Gas Lift	68
	Summary	69
9	Recovering the Rest of the Oil	71
	Waterflooding	73
	Miscible Processes	74
	Thermal Processes	76
	Summary	78
10	Separating and Treating Reservoir Fluids	79
	Separation	80
	Treating Oilfield Emulsions	86
	Field Handling of Natural Gas	89
	Offshore Production	93
	Summary	94
11	Understanding Well Performance	95
	Potential Tests	95
	Bottomhole Pressure Tests	98
	Productivity Tests	99
	Special Tests	99
	Summary	100
12	Storing and Measuring Oil and Gas	101
	Storage	101
	Measurement	103
	LACT Units	104
	Computers	106
	Summary	106
13	When Special Problems Occur	107
	Corrosion	107
	Scale	109
	Water Disposal	110
	Paraffin	110
	Hydrogen Sulfide	112
	Summary	113
	The Short Story	115
	Appendix: Figure Credits	117
	Glossary	125
	Index	155

Figures

1.1	When magnified, the pores in a rock are visible.	4
1.2	A rock is permeable when its pores are connected.	4
1.3	Microscopic organisms such as these lived in ancient seas.	5
1.4	The organic theory states that oil and gas were formed from the remains of microscopic plants.	6
1.5	Earthquakes moved huge blocks of earth up, down, and sideways.	6
1.6	Layers of rock were folded into arches and troughs.	7
1.7	Once formed, petroleum was forced to move upward through tiny fissures or pore spaces in the rock.	7
1.8	An anticline can trap oil or gas that has migrated into a porous and permeable rock layer.	8
1.9	In a fault trap, the layers on one side of the fault have moved opposite the petroleum-bearing layer on the other side.	9
1.10	An angular unconformity below Carbon Creek, Grand Canyon National Park in Arizona	9
1.11	Traps associated with salt domes usually occur on the sides of, and sometimes above, the dome.	10
1.12	A change of permeability within a rock layer can form a trap.	10
1.13	A combination of folds and faults in association with an unconformity can trap hydrocarbons.	11
1.14	Salt water often lies underneath oil and gas in a reservoir.	11
1.15	Salt water usually coats the grains of the reservoir rock.	11
2.1a	Vibrator trucks travel to locations to impose low-frequency sound waves through rock layers.	14
2.1b	Sound waves travel down through the earth and back to detection devices on the surface.	15
2.2	A record or seismic section can reveal the presence of possible petroleum traps.	15
2.3	Three-D seismic compiles a series of sections to create a cubic picture that shows types of rock, their depths, and whether a hydrocarbon trap is possibly present.	16
2.4	A 4D seismic is a time-lapsed view of 3D seismic surveys acquired at different times in the productive life of a reservoir.	17
2.5	A bright spot (shown in red and yellow) can sometimes indicate the occurrence of hydrocarbons.	17
2.6	Major systems of oil rig drilling equipment	19
2.7	The rotary table is one method of rotating the string of pipe and the bit.	19

2.8	The teeth of the bit penetrate the rock, scraping and gouging away to make a hole.	19
2.9	A typical mud pump	20
2.10	Cuttings made by the bit are lifted to the surface by the returning mud flow and then separated from the mud by the shale shaker.	21
2.11	A bit inside the conductor casing drills out the dirt inside the casing and continues drilling into the ground.	21
2.12	Drilling stops temporarily at a depth well above the trap.	22
2.13	Surface casing is run inside the conductor casing and the drilled hole.	22
2.14	Cement is pumped down inside the surface casing and up the annulus.	23
2.15	Surface casing is cemented in place inside the conductor and the hole.	23
2.16	Several directional wells tap an offshore reservoir.	24
2.17	A blowout and resulting fire at Greenhill Well in Timbalier Bay, Louisiana	25
2.18	Intermediate casing is cemented in the well.	25
3.1	Some types of offshore platforms	28
3.2	ConocoPhillips Britannia Platform in the North Sea	29
3.3	A floating production, storage, and offloading system, known as FPSOs, operated by ConocoPhillips	30
4.1	A well log is examined to see whether it indicates the presence of hydrocarbons and other fluids in a formation.	34
4.2	Conductor, surface, intermediate, and production casing are cemented in the well.	35
4.3	A perforating gun is used to create holes, or perforations, in the casing, cement, and production formation allowing petroleum in the reservoir to enter the well.	35
4.4	An open-hole completion allows reservoir fluids to flow into the uncased hole.	36
4.5	A production liner is hung inside a previously run string of casing.	36
4.6	In a perforated liner completion, the shortened length of casing or liner is perforated opposite the producing zone.	37
4.7	A wire-wrapped screen completion often runs with a gravel pack inside perforated casing.	37
4.8	Tubing is run in a perforated well so reservoir fluids can flow to the surface efficiently.	38

4.9	A packer placed in the tubing string keeps reservoir fluids out of the tubing-casing annulus.	39
4.10	A subsurface safety valve is installed in the tubing string.	39
4.11	A tubingless completion has no inner tubing string.	40
4.12	A multiple completion, such as this triple one, usually has a separate tubing string and packer for each producing zone.	40
5.1	When the hole is being drilled, drilling mud can seep into a permeable formation.	43
5.2	Several powerful, truck-mounted pumps are arranged at the well site to perform fracturing.	44
5.3	Reservoir fluids flow into the fracture and well.	45
5.4	Acid is injected down the tubing and into the reservoir through perforations to remove formation damage without fracturing the formation.	45
6.1	In a dissolved-gas drive reservoir, gas leaves the oil, expands, and lifts the oil to the surface	47
6.2	In a gas-cap drive reservoir, the free gas in the cap and the gas dissolved in the oil expand to move oil up to the surface.	48
6.3	In a water-drive reservoir, salt water under the oil invades to push oil to the surface.	49
6.4	In a combination-drive reservoir, expanding gas in the cap, gas dissolved in the oil, and water under the oil drive oil to the surface.	50
7.1	A typical wellhead is made up of one or more casingheads, a tubing head, and a Christmas tree.	53
7.2	In this example, two casingheads are used on top of three strings of casing.	54
7.3	Less complex casingheads can be used in wells that have only two casing strings.	54
7.4	A tubing head can be installed on top of the casinghead.	55
7.5	A tubing head can be connected directly to casing without the use of a casinghead.	55
7.6	The Christmas tree is mounted on top of the tubing head.	56
7.7	A Christmas tree has several valves that can be opened or closed to control the flow of fluids from the well.	57
7.8	A choke housed inside the fitting controls the fluids flowing from the Christmas tree.	58
8.1	A beam pumping unit operates on the surface.	60
8.2	A sucker rod pump can be attached to, or installed inside, the tubing string.	61

8.3	A beam pumping unit with wellhead, sucker rods, and sucker rod pump is one method of artificial lift.	61
8.4	Several joints of sucker rods will be lowered into the well.	62
8.5	A sucker rod coupling connects the sucker rods.	62
8.6	A sucker rod pump lifts well production to the surface.	63
8.7	The tubing pump (A) and the insert pump (B) are two basic sucker rod pump designs.	64
8.8	A hydraulic pumping system has surface and subsurface components.	65
8.9	A subsurface, or downhole, hydraulic pump consists of pistons, ports, and valves.	66
8.10	In an electric submersible pump, an electric motor turns impellers in the pump.	67
8.11	Gas-lift valves are installed in the tubing string at various depths.	68
8.12	Space is limited on offshore production platforms.	69
9.1	Primary, secondary, and tertiary or enhanced recovery processes.	72
9.2	In waterflooding, water is injected into wells around the producing well.	73
9.3	During enhanced recovery, one type of chemical miscible process injects water containing a surfactant into the reservoir.	74
9.4	A kind of gas miscible process involves injecting CO ₂ into the reservoir.	75
9.5	In steam flooding, steam and hot water thin the oil and move it to producing wells.	76
9.6	In the huff-and-puff method (left to right), steam is injected into the reservoir, then the well is closed in and allowed to soak.	77
9.7	In the fire flood method, compressed air is injected into the reservoir and the oil is ignited.	77
10.1	This photomicrograph shows droplets of water suspended and dispersed throughout the oil in a water-in-oil emulsion.	79
10.2	This vertical separator is a hollow steel vessel that receives the reservoir fluids from the well.	80
10.3	A two-phase separator separates well fluids into liquid and gas.	81
10.4	A three-phase process separates well fluids into gas, oil or emulsion, and water.	81
10.5a	A horizontal separator	82
10.5b	A horizontal separator can be a single-tube (top) or a double-tube (bottom) design.	83
10.6	A spherical separator is a ball-shaped vessel, shown here on an offshore production platform.	83

10.7	A mist extractor traps droplets of liquid as gas passes through in this two-phase separator.	84
10.8	Baffles help gas break out of oil in this vertical, two-phase separator.	85
10.9	Stock tanks such as these are used to store oil on the lease.	85
10.10	A vertical heater-treater aids in breaking emulsion.	86
10.11	Components and treating action of a vertical heater-treater	87
10.12	Components and operation of a horizontal heater-treater	88
10.13	Components and operation of an electrostatic heater-treater	89
10.14	An indirect heater prevents water condensation and hydrate formation in gas flow lines.	90
10.15	An indirect heater warms the water bath, which, in turn, warms gas flowing through the tube bundle.	91
10.16	A glycol dehydrator removes most of the water vapor from natural gas.	91
10.17	A glycol dehydration system consists of a glycol absorber, pump, surge tank, and reboiler.	92
10.18	Bubble caps on bubble trays inside the absorber (left) and a close-up of a bubble cap (right) show how wet gas bubbles through dry glycol.	93
11.1	One type of well-testing system diverts the well fluids into a test separator where the gas is measured with an orifice meter and the oil is measured in the stock tank.	96
11.2	To measure the depth of the oil in a tank, a special flexible steel measuring tape is lowered into the stock tank.	97
11.3	Micro Motion 3000 Series Net-Oil Computer with Elite High Capacity Coriolis meter	97
11.4	A bottomhole pressure gauge is lowered into the well on wireline.	98
12.1	A top view of a tank battery	101
12.2	An oil sales outlet is located near the bottom of each stock tank.	102
12.3	A thief hatch (shown open) is located on the top of each tank.	102
12.4	A thief is a special calibrated cylinder used to obtain a sample of oil from the tank.	103
12.5	A LACT unit automatically transfers crude oil from the lease to the pipeline.	105
12.6	Computers are important to many modern production operations.	106
13.1	A chemical injection pump is often used to inject corrosion inhibitors into the well stream.	108

13.2	Scale deposits can decrease the flow capacity of pipes.	109
13.3a	Paraffin can build up and inhibit flow through tubing.	110
13.3b	Special processes must be used to remove paraffin to allow a well to flow at acceptable rates.	111
13.4	Protection from the harmful effects of H ₂ S includes the use of special breathing equipment.	112